

## INSTALLATION INSTRUCTION LED DESIGNER SURFACE PENDANT

### TECHNICAL DATA:

Model	VT-7308
Watts	
Lumens	
Color	CCT (Dimmable)
Beam Angle	
Body Type	Aluminum + PC lamp body
Input Power	AC:220-240V, 50/60Hz
Dimension	
Remote Control Type	Remote Control 2.4G RF




### INTRODUCTION & WARRANTY


Thank you for selecting and buying V-TAC product. V-TAC will serve you the best. Please read these instructions carefully before starting the installation and keep this manual handy for future reference. If you have any another query, please contact our dealer or local vendor from whom you have purchased the product. They are trained and ready to serve you at the best. The warranty is valid for 3 years from the date of purchase. The warranty does not apply to damage caused by incorrect installation or abnormal wear and tear. The company gives no warranty against damage to any surface due to incorrect removal and installation of the product. The products are suitable for 10-12 Hours Daily operation. Usage of product for 24 Hours a day would void the warranty. This product is warranted for manufacturing defects only.

### WARNING

1. Please make sure to turn off the power before starting the installation.
2. The light source of this luminaire is not replaceable, when the light source reaches its end of life the whole luminaire should be replaced.
3. If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
4. Proper grounding should be ensured throughout the installation.
5. Installation must be performed by a certified person.
6. For Indoor use only
7. Switch off the power in case of abnormal performance and contact professional technician or local dealer



Caution, risk of electric shock.



Non-replaceable control gear


Non-replaceable light source



### MULTI-LANGUAGE MANUAL QR CODE

Please scan the QR code to access the manual in multiple languages.

### INSTALLATION DIAGRAM:



### INSTALLATION INSTRUCTION

1. Switch off the power before starting the installation.
2. Fix the ceiling plate to the ceiling with screw.
3. Connect supply wires to luminare as displayed in the wiring diagram.
4. Then fix the ceiling base to the ceiling plate with screw accordingly.
5. Switch on the lamp to check the light.

### MAINTENANCE

1. Clean and check the lamp on time for safety and better performance
2. Switch off the power before cleaning

**IN CASE OF ANY QUERY/ISSUE WITH THE PRODUCT, PLEASE REACH OUT TO US AT: SUPPORT@V-TAC.EU  
FOR MORE PRODUCTS RANGE, INQUIRY PLEASE CONTACT OUR DISTRIBUTOR OR NEAREST DEALERS. V-TAC EUROPE LTD. BULGARIA, PLOVDIV 4000, BUL.L.KARAVELOW 9B**

## REMOTE CONTROL INSTRUCTION

### REMOTE CONTROL BUTTON FUNCTIONS

**Turn on button:** Press turn on button once, the fixture will switch on. To match the code, hold long press turn on button within 4s (seconds) after connecting power supply successfully.

**Turn off button:** Press turn off button once, the fixture will switch off. To clear the code, hold long press turn off button within 4s (seconds) after connecting power supply successfully.

#### Cold light +:

1. Press cold light once, the lighting fixture will add one grade brightness, in the meanwhile, the warm light of lighting fixture will reduce one grade brightness. There is total 15 different brightness grades from cold light to turn off light and to turn on light.

2. Hold long press cold light button, cold light of lighting fixture become brighter gradually, at the same time the warm light of lighting fixture become darker.

#### Warm light +:

1. Press warm light once, the lighting fixture will add one grade brightness, in the meanwhile, the cold light of lighting fixture will reduce one grade brightness. There is total 15 different brightness grades from warm light to turn off light and to turn on light.

2. Hold long press warm light button, warm light of lighting fixture become brighter gradually, at the same time the cold light of lighting fixture become darker.

#### Brightness +:

1. Once press "brightness +" button, cold light and warm light of lighting fixture would add more one grade brightness, there is total 11 brightness grades from the lowest brightness to the highest brightness.

2. Hold long press "brightness +" button, cold light and warm light of lighting fixture would be more brighter gradually at the same time.

#### Brightness -:

1. Once press "brightness -" button, cold light and warm light of lighting fixture would reduce one grade brightness, there is total 11 brightness grades from the highest brightness to the lowest brightness.

2. Hold long press "brightness -" button, cold light and warm light of lighting fixture would be darker gradually at the same time.

#### Button indicating light using way as below:

**Note:** Customer can adjust warm light and cold light settings according to power supply and fixture.

### HOW TO CONNECT/DISCONNECT REMOTE CONTROL WITH THE FIXTURE

#### 1. Match Code function:

[The remote control only can be used after matching code with the LED lamps], follow the below method

- Turn off LED power supply for 10s (seconds), then turn on LED power supply, long press turn on button within 4s (seconds) at once, if LED lamp will flash once slowly, it means match code is successful.

**Note:** Lighting fixture can only control by last successful match code.

- For instance, one lighting fixture can match code with many remote controls successfully, but only recent matched remote control can control this lamp, those previous remote control record will be auto clear by the system.

**2. Clear code function:** Turn off LED power supply for 10s (seconds), then turn on LED power supply, long press turn off button within 4s (seconds) at once, if LED lamp will flash twice slowly, it means clear code successfully.

**Note:** Clear code function based on fixture has matched code already, if not matched then long pressing the turn off button will result in no effect.

#### For example:

- 1) There is no clear code function, if this remote control do not match code with fixture first.
- 2) Finish match code and then process clear code.
- 3) If fixture already match code and then you use another new remote control to match code again, the previous remote control record would be auto-cleared by system, so now LED will be without clear code function now.

**3. Remote control with remember record function after powering off.** Fixture brightness and match code record will keep stay on LED remote control's storage after using remote control adjust fixture brightness. So it can use previous remote control to control previous lamp after powering on.

