

## Operation Manual of Solarman App Local Mode for XG inverters

### Preparation:


- 1) Latest version of Solarman App
- 2) WiFi logger with latest firmware (**Please check with manufacturer whether remote upgrade is required**)

### Operation:


1. Turn on the bluetooth of mobile phone




2. Login Solarman App and enter the Local Mode




3. Scan the QR code of the wifi logger



4. After connection you can view the Real-time data and set the Parameters




5. Before setting the Parameters please first turn off the inverter on App, and turn it on after all settings finished. Refer to the following example:



A

B



C

D