



WEEE Number: 80133970

# USER MANUAL

## SPEAKER (VT-6207-2)



### INTRODUCTION & WARRANTY

**1** YEAR  
WARRANTY \*


Thank you for selecting and buying V-TAC Product. V-TAC will serve you the best. Please read these instructions carefully & keep this user manual handy for future reference. If you have any another query, please contact our dealer or local vendor from whom you have purchased the product. They are trained and ready to serve you at the best. The warranty is valid for 1 year from the date of purchase. The warranty does not apply to damage caused by incorrect usage or abnormal wear and tear. The company gives no warranty against damage to any surface due to incorrect usage of the product. This product is warranted for manufacturing defects only.



### Multi-Language Manual QR CODE

Please scan the QR code to access the manual in multiple languages.

## PANEL FUNCTION



1. USB/ TF/AUX
2. MIC INPUT
3. DC INPUT
4. POWER: ON/OFF
5. ADJUST THE VOLUME OF MICROPHONE
6. ECHO
7. ADJUST THE VOLUME OF WHOLE UNIT
8. BASS
9. TREBLE
10. PREVIOUS SONG
11. PLAY/PAUSE
12. NEXT SONG
13. INTERCHANGE
14. REC
15. LED

## REC FUNCTION

### HOW TO USE RECORDING FUNCTION:


**STEP 1:** Make sure the unit is switched on, and there is a USB memory stick or TF card inserted in the slot.

**STEP 2:** Plug and test the microphone upon plugging. The device is ready to record once your voice is audible from the speaker.



**STEP 3:**

Press the button 'REC' on the remote control to start/stop recording, you are freely to rec what you want.

Press the button 'REC/PLAY' to play your recording.



## REMOTE FUNCTION



1. MUTE: Press this button to mute the unit.
2. Press this button to toggle between the various inputs (AUX,USB,SD,FM, BLUETOOTH), Long press this button to turn on/off the voice prompt.
3. Press button to start recording.
4. Press this button to increase the master volume for the unit.
5. Press this button to pause or play the unit when it is on the mode of USB. When it is on the mode of FM, press this button to auto scan all channels. Long press to change language to Chinese/English for the voice prompt.
6. Press this button to select the previous song/channels
7. Press this button to reduce the master volume for the unit.
8. Press this button to repeat one/repeat all.
9. Press this button to play the recording.
10. Press this button to select the next song/channel.
11. Press this button to the EQ mode of Normal, Jazz, Rock, POP & Classical
12. 0-9, Key number for selecting the certain songs in the USB/SD/TF Card.

---

## WIRELESS FUNCTION

STEP 1: In the front panel, press the mode button to launch the Bluetooth application. This will show the Bluetooth logo show on the screen.

STEP 2: Toggle the Bluetooth switch on to activate. The device will automatically begin to scan for nearby Bluetooth devices.

STEP 3: Tap "V-TAC VT-6207-2" on your list of devices. Depending on the device you are trying to connect the speaker to, it may be necessary to enter a pass code. Enter the default passcode "0000" if prompted by the device. Then, wait for your device to be connected successfully.

STEP 4: Tap the entry for bluetooth accessory when it is detected by the smart phone or computer and displayed on the screen. Then it can use bluetooth to operate in conjunction with accessory.

## CHARGING INDICATOR

**Charging:** The led light will be in red color

**Full:** When full-charged the led light will be in green color.

**Charging Time:** 2 to 4 hours

**Working Time:** 5 to 6 hours

## TECHNICAL SPECIFICATIONS

- Frequency Range: 2.4-2.48Ghz
  - Working Distance: up to 15 meters in open space.
  - Supporting: USB/TF card play
  - FM Radio: frequency 87.5~1080MHz
  - Remote Control: up to 5 meters in open space.
  - LED light with on/off Switch
  - Output power:30w
  - Distortion  $\leq$  1.0%
  - Frequency response: 180Hz-20Khz
  - Microphone sensitivity: -40dB
  - Working time: Music time 2 to 4 hours
  - Input jack: Aux input, wired microphone input
  - Charging input power: DC 9V INPUT (Power Adaptor - AC:100-240V)
  - Charging time: 5 to 6 hours
-

---

## **INSTRUCTIONS**

1. This unit uses a rechargeable battery. When the battery power is depleted, please plug the device to an electric socket with the correct input voltage.
2. When the unit is charging, please make sure to switch on the AC/DC option, then safely unplug when finished.
3. On first use, the battery must be charged for 10 to 12 hours.
4. The unit's battery working time lasts up to 2 to 4 hours, depending on the usage.

## **ATTENTION**

1. To maintain battery life, please charge the battery every time the power is completely depleted. Damage may occur if the battery is not charged for longer periods, so please use and charge the battery at regular intervals.
2. Our company reserves the right to update the product without any notice.
3. If you have any issue with the product, kindly contact a professional technician. Do not open the unit yourself.
4. For safety reasons, keep the device away from children.